

BaByliss
PARIS

www.babylisskorea.com

Conair Far East Ltd.,
A Subsidiary of Conair Corporate USA Conair
Corporation USA.,
1 Cummings Point Road, Stamford,
Connecticut 06902 USA

수입 판매원
콘에어코리아트레이딩주식회사
서울시성동구성수이로 66
서울숲드림타워 1304~1306호
A/S 대표 번호 : 1899-0209
자사의 A/S 전문대행업체인 필리렉 www.fillex.co.kr
의 홈페이지를 통해서
가까운 A/S센터(전국 38개점)를 확인하세요

ST270K

IB-16/401

BaByliss®
PARIS



2 in 1 Curl & Straightener

'i curl' by BaByliss, the straightener used by professionals, is a revolutionary straightener, using the latest technology, that can straighten and curl your hair in just one stroke.

You will be pleased by the efficiency of the new Ceramic Intense plates. Smoother, they guarantee perfect glide for an impeccable result and for respecting your hair even more.

Please carefully read the instructions for use below before using the appliance.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

SAFETY PRECAUTIONS

WARNING: The polyethylene bags over the product or its packaging may be dangerous. Keep these bags out of the reach of babies and children.



Never use them in cribs, children's beds, pushchairs or playpens. The thin film may cling to the nose and mouth and prevent breathing. A bag is not a toy.



WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

- If you are using the unit in a bathroom, unplug it after you have finished using it. Using the unit close to a source of water can, in fact, be dangerous, even if the unit is switched off. To ensure additional protection, have installed in your bathroom a residual current device (RCD) with a nominal trip current no higher than 30 mA. Ask your electrical fitter for advice.
- Never immerse the unit in water or any other liquid.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Do not use the unit if it has fallen or if it appears to be damaged.

- Do not leave the unit unattended when it is plugged in or switched on.
- Unplug the unit immediately if you have problems when using it.
- Do not use any accessories other than those recommended by manufacturer.
- Unplug the unit after each use and before cleaning it.
- Avoid any contact between the unit's hot surfaces and your skin, in particular, your ears, eyes, face and neck.
- This unit is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or by persons who lack experience or knowledge, unless they are supervised or have been given instructions beforehand on the use of the unit by a person responsible for their safety. Children should be supervised to make sure they do not treat the unit like a toy.
- Allow the unit to cool before storing.
- To prevent damage to the cord, ensure it is stored without twisting or folding it.
- Before plugging in, read the information about worldwide voltage contained in the operating instructions section of this manual.
- Do not use with a voltage converter.

WORLDWIDE VOLTAGE

This appliance will automatically adjust to the proper voltage. Use an adapter plug with correct configuration prior to use in outlet.

PRODUCT FEATURES

- Flat plates to straighten, size of the plates: 24 mm x 90 mm
- Curved plates to curl
- Professional plates with Ceramic Intense coating
- 2 temperature settings - 150 °C (150) - 230 °C (230)
- Operated indication light (LED)
- Swivel cord
- Locking system to keep the plates closed
- Cool Tip

- If you are using the unit in a bathroom, unplug it after you have finished using it. Using the unit close to a source of water can, in fact, be dangerous, even if the unit is switched off. To ensure additional protection, have installed in your bathroom a residual current device (RCD) with a nominal trip current no higher than 30 mA. Ask your electrical fitter for advice.
- Never immerse the unit in water or any other liquid.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Do not use the unit if it has fallen or if it appears to be damaged.

- Do not leave the unit unattended when it is plugged in or switched on.
- Unplug the unit immediately if you have problems when using it.
- Do not use any accessories other than those recommended by manufacturer.
- Unplug the unit after each use and before cleaning it.
- Avoid any contact between the unit's hot surfaces and your skin, in particular, your ears, eyes, face and neck.
- This unit is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or by persons who lack experience or knowledge, unless they are supervised or have been given instructions beforehand on the use of the unit by a person responsible for their safety. Children should be supervised to make sure they do not treat the unit like a toy.
- Allow the unit to cool before storing.
- To prevent damage to the cord, ensure it is stored without twisting or folding it.
- Before plugging in, read the information about worldwide voltage contained in the operating instructions section of this manual.
- Do not use with a voltage converter.

- Do not leave the unit unattended when it is plugged in or switched on.
- Unplug the unit immediately if you have problems when using it.
- Do not use any accessories other than those recommended by manufacturer.
- Unplug the unit after each use and before cleaning it.
- Avoid any contact between the unit's hot surfaces and your skin, in particular, your ears, eyes, face and neck.
- This unit is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or by persons who lack experience or knowledge, unless they are supervised or have been given instructions beforehand on the use of the unit by a person responsible for their safety. Children should be supervised to make sure they do not treat the unit like a toy.
- Allow the unit to cool before storing.
- To prevent damage to the cord, ensure it is stored without twisting or folding it.
- Before plugging in, read the information about worldwide voltage contained in the operating instructions section of this manual.
- Do not use with a voltage converter.


CONTINENTAL CONAIR LIMITED CHINA CREATIVE DEPARTMENT

Date	10/14/2016
Customer	CKTL
Model No.	ST270K
Description	IB
Job No.	16BB018
Reference No.	IB-16/401
Revision No.	0
Color	1C(BLACK) + 1C(BLACK)
Open Size	630mm(W) X 165mm(H)
Folded Size	90mm(W) X 165mm(H)
Material	105 gsm matt Artpaper
Prepared by	Carlos Ho
Approved by	Jimmy Ng
Vendor	MILLPLAN
Supplier	

5 cm width and place it between the 2 hot plates with the appliance positioned close to the roots, being careful to avoid touching the hot surface of the appliance with your hand.

- Hold the hair firmly with the straightener and slide slowly along from the roots to the tips.
- Repeat again if necessary.
- Let the hair cool down before you comb it.
- After use, switch off and unplug the appliance. Allow to cool before storing away.

• Remove the '2 in 1' straightener and use your fingers to twist the section again so that it takes its natural position.



Note! When you use the unit, you may hear some sizzling and notice a little steam. This is normal and may result from the evaporation of sebum, residual hair products (leave-in care, hair spray, etc.) or from excess water that is evaporating from your hair.

USER MAINTENANCE

Your straightening is virtually maintenance-free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CURLING YOUR HAIR

- Take up a section about 2 to 3 cm wide and place it between the 2 heating plates, near the roots of your hair.



INSTRUCTIONS FOR USE

The first time you use the unit, you may notice a little steam and a particular odor: this is common and will disappear the next time you use it.

- Turn the '2 in 1' straightener 180° upwards.



- Slowly glide the '2 in 1' straightener over the length of the section, from the roots to the tips.



CAUTION

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections.


THE DATE CODE MENTIONED

WWYYXX was mentioned on unit as manufactured date so you can see W as week and Y as year for your reference.

STRAIGHTENING YOUR HAIR

- Thoroughly brush hair and section.
- Start with the underneath sections of hair. Take a section of about

折疊方法
Folding method:
14 pages (7 x 2)



2 IN 1 아이 컬 & 스트레이트너

바비리스 아이 컬은 한 번의 슬라이딩으로 활랑 거리는 스트레이트 스타일 또는 컬을 연출할 수 있는 혁신적인 제품입니다. 본 제품은 세라믹 인텐스 코팅 열판으로 부드럽게 모발에 슬라이딩하여 모발 컨디션을 최상으로 지켜줍니다. 아래의 사용 설명서를 숙지 후 사용하시기 바랍니다.


주요 안전 주의 사항

제품 사용 시 특히 어린이가 있을 경우, 아래 안전 수칙을 포함한 기본 안전 수칙을 반드시 지켜 주십시오.


사용 전 반드시 사용 설명서를 숙지해 주십시오.
절대 물에 접촉하거나 빠뜨리시면 안됩니다.

주의 사항

경고: 제품 포장에 사용된 폴리에틸렌 재질의 포장재는 어린이가 사용할 경우 위험할 수 있습니다. 어린이의 손이 닿지 않도록 주의해 주십시오. 이 포장재를 유아용 침대, 유모차 또는 유아용 놀이 공간 등에서 사용하지 마십시오. 짚은 필름 막이 코나 입에 붙어 유아나 어린이가 질식될 수 있습니다. 포장재는 장난감이 아닙니다.



경고: 본 제품은 육조, 사워장, 세면대 등 물이 닿기 쉬운 곳에서 사용하지 마십시오.



- 옥실에서 본 제품을 사용할 경우, 사용 후 반드시 플러그를 빼주십시오. 제품의 전원이 차단되어 있어도 물이 닿을 경우 위험할 수 있으니 안전을 위해 화장실에 누전차단장치를 설치하기를 권장합니다. 보다 안전한 사용을 위하여 옥실의 전류 전류 용량은 30mA이하여야 합니다.
- 물 또는 액체에 절대 빠뜨리지 마십시오.
- 전원코드가 손상되었을 경우 반드시 A/S 센터에 수리를 받으셔야 안전합니다.
- 제품에 강한 충격이 가해졌거나 이상이 있는 것처럼 보이면 사용하지 마십시오.
- 스위치를 켜 두거나 플러그를 끊어둔 상태에서 자리를 비우지 마십시오.
- 사용 중 문제가 생기면 바로 플러그를 뽑으십시오.
- 제조업체가 공급하지 않는 부품은 사용하지 마십시오.
- 제품 사용 후나 청소 하기 전, 반드시 플러그를 뽑으십시오.

- 열판의 표면이 뜨거운 제품이 귀나 눈 등 피부에 직접 닿지 않도록 합니다.
- 본 제품은 움직임이 불편한 사람, 영유아, 어린이, 심신 박약자, 심신 상실자, 정신 질환자 등에 의해 사용 되어서는 안되며 사용시에는 반드시 안전을 책임지는 보호자의 지도로 사용하세요.
- 제품 보관 시에는 반드시 기기의 열을 식힌 후 보관 하십시오.
- 전원 코드의 손상을 방지하기 위해 코드로 기기를 감지 마시고 꼬거나 접힌 상태로 보관하지 마십시오.
- 플러그를 연결하기 전, 아래의 '전 세계 범용 전압'에 대한 설명을 숙지하시기 바랍니다.
- 전압 변환기(컨버터)와 함께 사용하지 마십시오.

전 세계 범용 전압

본 제품은 자동적으로 전압을 변환합니다. 연결하시려는 전기 콘센트에 맞는 플러그인지를 확인 후 연결하시기 바랍니다.

제품 특징

- 스트레이트 스타일 연출용 납작한 열판, 열판 사이즈 24MM x 90MM
- 컬 연출용 등근 열판
- 전문가용 세라믹 집중 코팅 열판
- 온도 조절 - 150°C (150°C) - 230°C (230°C)
- 기기 작동 표시 LED 라이트
- 360° 회전식 코드
- 편리한 보관을 위한 열판 잠금 스위치
- 쿨 팀

사용방법

본 제품을 처음 사용하실 때, 약간의 스팀이 발생하고 제품 특유의 냄새가 날 수도 있습니다. 이는 제품 처음 사용 시에 나타나는 일반적인 현상으로 안심하고 사용하셔도 됩니다.

*

물기를 제거한 모발에 사용합니다.

*

플러그를 연결 후, 원하시는 온도를 스위치로 조절하십시오. 웨이브를 연출할 때에는 150°C (150°C), 스트레이트 스타일을 연출할 때에는 230°C (230°C)로 세팅하는 것이 적절합니다.


스트레이트 스타일 연출 시 가늘고 손상된 모발에는 낮은 온도, 웨이브 스타일 연출 시 두껍고 뱃뻣한 모발에는 높은 온도로 설정하여 사용하시기 바랍니다. 모발 상태는 개인마다 다르기 때문에 처음 사용 할 때에는 150°C로 세팅하여 사용해 보시고, 이후에 사용할 때 모발 상태에 따라 온도를 높여 사용하는 것을 권장합니다.

*

스트레이트 열판이 예열되기까지는 약 1분정도가 소요됩니다.

모발 스트레이트닝

* 모발 전체를 빛질하여 정리해 줍니다.



- * 스타일링 시 모발 안쪽부터 스타일링 해주십시오. 5CM 정도로 모발 셀션을 나누어 두 열판 사이에 넣어줍니다. 열판 표면이 뜨거운 주의 하십시오.
- * 모발을 단단히 잡고 모발 뿌리부터 끝까지 천천히 슬라이딩하여 스타일을 연출하십시오.
- * 원하시는 스트레이트 스타일이 연출되기까지 위 동작을 반복하십시오.
- * 모발을 식힌 후 빛질로 정돈합니다.
- * 사용 후에는 반드시 전원을 끄고 플러그를 분리하여 보관하십시오.
- 주의!** 스타일링을 할 때 '치익' 소리가 나거나 스팀이 발생하는 것은, 일반적으로 모발에 남아있는 헤어 제품(헤어 스프레이 등)이나 건조되지 않아 남아있는 수분 등이 증발하면서 나타나는 현상입니다.



- * 아래 그림과 같이 손가락으로 모발을 휘어 감아 웨이브가 자연스럽게 자리 잡히도록 합니다.



품질보증서

- 본 제품은 품질관리와 제품검사를 거쳐 출고됩니다.
- 사용자의 정상적인 사용상태에서 하자가 발생했을 경우 보증서의 내용대로 낸 내에서 구입처나 A/S센터에서 제품교환 또는 무상서비스를 받으실 수 있습니다.
- 보증기간이라도 비용을 받는 경우는 다음과 같습니다.
 - 사용자의 과오로 인한 하자 또는 파손인 경우
 - 부당한 수리 또는 개조로 인한 하자 또는 파손인 경우
 - 천재지변에 의한 하자 또는 파손인 경우
 - 구매 후 이동 또는 낙하등에 의한 하자 또는 파손인 경우
 - 사용설명서 내의 위험, 경고 또는 주의사항을 지키지 않아 발생한 하자인 경우
- 본 증서를 잘 보관하고 서비스를 받으시고자 할 경우 보증서의 내용을 기록하여 제품과 함께 보내주십시오.

보증기간:

구입일로부터 1년

제품명:

모델명:

구입일자:

구입처(상호):

고객성명:

성별 남 여

고객주소:

전화번호:

※

본 사용설명서에 예시되어 있는 제품의 사양과 디자인은 예고 없이 변경될 수 있습니다.

수입 판매원

코에어코리아트레이딩주식회사
서울시 성동구 성수로 166 서울숲드림타워 1304~1306호


A/S 대표 번호 :

1899-0209

A/S 대표 번호 : 1899-0209
자사의 A/S 전문대행업체인 필립스 www.filipac.kr 의 홈페이지를 통해서
기꺼운 A/S센터(전국 38개점)를 확인하세요

보관 방법

제품을 사용하지 않을 때에는 반드시 전원을 분리하고 제품을 차갑게 식힌 후 어린이의 손이 닿지 않는 안전하고 건조한 곳에 보관하십시오. 전원에서 플러그를 분리할 때에 갑자기 코드를 잡아당기거나 너무 팽팽하게 당기지 마십시오.



날짜코드

WWYYXX는 제조 일자로서 W는 '주' 단위, YY는 '년' 단위로 보시면 됩니다.