

BaByliss®

www.babylisskorea.com

BaByliss 전 제품은 프랑스 BaByliss에서 개발·디자인되고 중국 현지 공장에서 생산되어, 다시 프랑스 BaByliss의 엄격한 품질검사 과정을 거친 제품입니다.

Conair Korea Trading Limited

수입 판매원
콘에어코리아트레이딩주식회사

소비자상담실: 1899-0209
A/S센터: 자사의 A/S대행업체인 필일렉
www.fillelec.co.kr의 홈페이지를 통해서 가까운
A/S센터(전국 38개점)를 확인하세요

HEC3K

IB-20/426

BaByliss®



GLOW BOLD EYELASHES CURLER

속눈썹 고데기

Ref.HEC3K

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

SAFETY PRECAUTIONS

WARNING: The polyethylene bags over the product or its packaging may be dangerous. Keep these bags out of the reach of babies and children.

Never use them in cribs, children's beds, pushchairs or playpens. The thin film may cling to the nose and mouth and prevent breathing. A bag is not a toy.

WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

1. Close supervision is required when this product is used on, by or near children or people with certain disabilities.
2. Use product only for its intended use as described in this instruction booklet.
3. Keep the unit away from heated surfaces.
4. Never use while sleeping or drowsy.
5. Do not use outdoors or where oxygen is being administered.
6. Never operate if the product is damaged.
7. Not for use by children.

ATTENTION:

1. If the heater is damaged, please stop using for your safety.
2. Remove battery if the product will not be used for an extended period.
3. There are no user-serviceable parts. If for any reason the unit does not function satisfactorily, return it to place of purchase. No repairs should be attempted by the consumer.

SENSITIVITY AND CAUTIONS

SPECIAL CAUTIONS FOR DELICATE AREAS

The Glow Bold Eyelashes Curler is intended to help you lift and style your lashes. The Glow Bold Eyelashes Curler is not a medical device and is not intended to be used to treat any medical conditions or to be used on false eyelashes.

If you are under a doctor's care for any skin condition or if you think you have very sensitive skin, please consult your physician before use.


We recommend not sharing the Heated Eyelash Curler; each user should have their own Heated Eyelash Curler.

Do not use with false eyelashes. Use the Glow Bold Eyelashes Curler prior to applying mascara.

If you experience any pain or discomfort during use, stop using and consult your physician.

Do not apply pressure when using the Heated Eyelash Curler.

GLOW BOLD EYELASHES CURLER FEATURES



HOW TO INSTALL BATTERY:


NOTE: The Glow Bold Eyelashes Curler operates on 1 AAA battery (not included).

1. Remove the battery cover until the battery door is released.
2. Install 1 AAA battery (not included) as per the markings in the battery compartment.
3. Replace the cover until the battery door is firmly closed.



INSTRUCTIONS FOR USING THE HEATED EYELASH CURLER

1. Remove the cap.
2. Slide On/Off switch up to preheat the curler. The temperature sensitive indicator will change color from blue to white when the curler is ready to use.
3. Carefully place the heating comb near the base of your lashes so that the curved tip fits the contour of your lashes, but not touching your eyelid. Hold the heating comb slightly upward for 8–10 seconds, then slowly slide it to the tips of your lashes. Repeat as needed to increase curl.
4. Follow with a coat of mascara if desired.
5. When finished, slide the switch down to turn off.



BEAUTY TIPS

How to get more beautiful, naturally curled lashes

1. Curl your eyelashes with this Heated Eyelash Curler.
2. Finish your look with a coat of mascara. Apply mascara by moving the brush back and forth at the base of your eyelashes, then slide up to the tips.

USER MAINTENANCE INSTRUCTIONS

CARING FOR YOUR GLOW BOLD EYELASHES CURLER

1. Clean the machine with a wet cloth or tissue if dirt develops on the unit after use.
2. Do not wash the unit with water.
3. Do not use abrasive cleaners for cleaning.
4. Do not put unit in dishwasher for cleaning.
5. When storing the heated eyelash curler, use the protective cover. This will prevent the heater from deforming.

TROUBLE-SHOOTING GUIDE

THE HEATED EYELASH CURLER IS NOT WORKING.	Make sure the battery is installed properly.
THE HEATED EYELASH CURLER HEATS UP SLOWLY.	Replace the battery.

INSTRUCTIONS FOR USING BATTERIES

1. Always purchase the correct size and grade of battery most suitable for the intended use.
2. Clean the battery contacts and also those of the device prior to battery installation.
3. Ensure the batteries are installed correctly with regard to polarity (+ and -).
4. Remove batteries from equipment that is not to be used for an extended period of time.
5. Remove used batteries promptly.
6. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.

BATTERY DISPOSAL

Batteries contain various materials that must be recycled and disposed of properly. Do not dispose of in the municipal waste system.


THE DATE CODE MENTIONED

WWYYXX was mentioned on unit as manufactured date so you can see W as week and Y as year for your reference.

CONTINENTAL CONAIR LIMITED CHINA CREATIVE DEPARTMENT

Date	2/2/2021
Customer	BaByliss-Korea
Model No.	HEC3K
Description	IB
Job No.	
Reference No.	IB-20/426
Revision No.	0
Color	1C(BLACK) + 1C(BLACK)
Open Size	720mm(W) X 165mm(H)
Folded Size	90mm(W) X 165mm(H)
Material	105 gsm matt Artpaper
Prepared by	Betty Bai
Approved by	Ken Xiong/Jay Jeon
Vendor	TONGHING
Supplier	

折叠方法
Folding method:
16 pages (8 x 2)



주요 안전 주의 사항

제품 사용 시 특히 어린이가 있을 경우, 아래 안전 수칙을 포함한 기본 안전 수칙을 반드시 지켜 주십시오.

**사용 전 반드시 사용 설명서를 숙지해 주십시오.
절대 물에 접촉하거나 빠뜨리면 안됩니다.**

안전 주의 사항

경고: 제품 포장에 사용된 폴리에틸렌 재질의 포장재는 어린이가 사용할 경우 위험할 수 있습니다. 어린이의 손이 닿지 않도록 주의해 주십시오. 이 포장재를 유아용 침대, 유모차 또는 유아용 놀이 공간 등에서 사용하지 마십시오. 얇은 필름 막이 코나 입에 붙어 유아나 어린이가 질식될 수 있습니다. 포장재는 장난감이 아닙니다.

경고: 본 제품을 욕조, 샤워장, 세면대 등 물이 닿기 쉬운 곳에서 사용하지 마십시오.

1. 영유아, 어린이, 혹은 제품 사용 경험이 없거나 미숙한 사람이 본 제품을 사용할 경우 화상을 입을 수 있으니 사용시엔 반드시 안전을 책임질 수 있는 보호자의 지도하에 사용하도록 하십시오. 특히 어린이가 장난감처럼 사용하지 않도록 각별한 주의 바랍니다.
2. 온도 외 절대로 사용하지 마시고 사용설명서에 따라 사용하십시오.
3. 뜨거운 표면이나 화기 근처에 두지 마십시오.
4. 사용 중 잡들거나 기면 중 사용하지 마십시오. 부상의 위험이 있습니다.
5. 본 제품은 실내 가정용입니다. 실외에서의 사용은 권장하지 않습니다.
6. 제품이 손상 및 파손된 경우 즉각 사용을 멈추고 전원을 끈 다음 자사의 A/S센터에 문의하십시오.
7. 장난감이 아닙니다. 어린이가 단독으로 사용하지 않도록 각별한 주의 바랍니다.

주의:

1. 열선이 손상 및 파손된 경우 절대 사용하지 마시고 즉각 전원을 차단하십시오.


2. 장기간 제품을 사용하지 않을 경우, 배터리를 분리하여 보관하십시오. 배터리의 누액으로 제품의 고장 및 손상을 유발합니다.
3. 사용자가 직접 수리하거나 조립하는 제품이 아닙니다. 본 제품의 성능에 문제가 발생된 경우 절대 직접 분해하거나 수리하지 마시고 구입처나 자사의 A/S센터에 문의하십시오.

사용 안내 및 주의 사항

피부가 예민하거나 현재 피부과 치료 및 시술을 받고 계신 경우 반드시 아래 내용을 숙지 하시기 바랍니다.

본 제품은 열을 사용하여 단시간 속눈썹을 들어올려 스타일링 하는데 도움을 주는 기기로 의료기기가 아니며 인조 속눈썹에 사용 시 손상될 수 있으니 사용을 금합니다.
현재 피부관련 치료를 받고 있거나 약물을 복용 중인 경우 혹은 피부가 매우 민감한 경우 반드시 사용 전 의사와 상의하십시오. 본 제품은 개인 미용 기기 이므로 위생을 위해 타인과 공유하지 마십시오.
인조 속눈썹에 사용하지 마십시오.
마스카라 전 본 제품을 사용하시기를 권장합니다.
마스카라 사용할 경우 제품의 열선에 남아있는 이물질을 반드시 제거한 후 보관하십시오.
제품 사용 중 통증이 느껴지거나 불편한 경우 즉각 사용을 중단하고 의사와 상담 하십시오.
사용 중 과도한 압력을 가하지 마십시오.

바비리스 글로우 속눈썹 고데기 안내



건전지 삽입:


주의: 본 제품은 1개의 AAA 건전지를 사용합니다. (건전지 별도구매).

1. 건전지 덮개를 아래로 살짝 내려 본품에서 분리하여 주십시오..
2. 1개의 AAA 건전지(별도구매)를 +/- 극에 맞춰 삽입하십시오.
3. 건전지 덮개를 완전히 닫아 주십시오.



바비리스 글로우 속눈썹 고데기 사용 방법

1. 상단의 열선 보호 캡을 제거하십시오.
2. 전원 스위치를 밀어 전원을 키면 예열이 시작됩니다. 상단의 변온 센서가 파란색에서 하얀색으로 변하면 예열완료를 나타내며, 바로 사용이 가능합니다. (예열시간 약 60초)
3. 속눈썹 라인에 맞춰 디자인된 커브형 열선을 속눈썹 뿌리 부근에 밀착하여 약 8-10초 간 지긋이 눌러 준 후 위로 천천히 쓸어 올려 주십시오. 지속력을 높이거나, 더 강한 컬을 원할 경우 위의 동작을 반복하십시오. **주의:** 화상의 위험이 있으니 눈꺼풀에 닿지 않도록 주의하십시오.
4. 필요에 따라 마스카라를 이용하시면 더 오랜 시간 컬을 유지할 수 있습니다.
5. 사용 후에는 전원 스위치를 밀어 전원을 끄고 충분히 식히십시오.



뷰티 팁! 자연스럽고 아름다운 속눈썹 컬 만들기

1. 바비리스 글로우 속눈썹 고데기를 사용하여 속눈썹을 컬링 하십시오.
2. 지속력을 높이고 또렷한 눈매를 원하실 경우 마스카라를 사용하여 고정하십시오. 마스카라 브러시를 속눈썹 뿌리쪽에서부터 바깥쪽으로 천천히 쓸어 올려 빗어 주십시오.

제품 관리 및 세척 방법

1. 사용 후 열선이 충분히 식은 후, 열선에 남은 유분이나 이물질을 깨끗한 천이나 티슈로 살살 닦아 주십시오.
2. 본 기기는 방수 제품이 아니므로 절대로 물 세척 하지 마십시오.
3. 연마제를 사용하여 세척하지 마십시오.
4. 식기 세척기에 넣지 마십시오.
5. 사용 후 보관시에는 열선을 충분히 식힌 후 보호캡을 씌워 보관하십시오.

문제 발생 시 가이드

전원이 켜지지 않을 경우	건전지가 올바르게 삽입되었는지 확인 하십시오.
예열 속도가 느린 경우	건전지의 수명이 다했을 수 있으니 새 건전지로 교체하십시오.

올바른 건전지 사용

1. 본 제품의 규격에 알맞은 건전지를 사용하십시오. 1 X AAA 사이즈(별도 구매)
2. 건전지 삽입 전 장치 및 건전지의 접점이 깨끗한지 확인 하십시오.
3. 건전지의 양극을 기기에 표시된 방향(+ / -)에 맞춰 삽입하십시오.
4. 장기간 사용하지 않을 경우 건전지를 제거하십시오. 건전지 누액으로 제품의 손상이 발생할 수 있습니다.
5. 수명이 다한 건전지는 즉시 제거하여 지역에서 권장하는 지침에 따라 폐기하십시오.
6. 오래된 건전지와 새 건전지를 함께 사용하지 마십시오. 또한 종류가 다른 건전지를 함께 사용하지 마십시오.(예: 알카인 건전지와 일반 건전지 등.)

건전지 폐기

수명이 다한 건전지는 일반 쓰레기와 함께 폐기하지 마시고, 지역의 폐기 규정에 따라 처리하거나 전용 수거함에 버려 주십시오. 폐건전지에서 수은이나 납이 흘러나와 환경에 영향을 끼칠 수 있습니다.

제조일 표기

제조일은 본 제품에 WWYYXXX형태로 표기되며 W는 '주 수', Y는 '년도'를 나타냅니다.

품질보증서

- 1 본 제품은 품질관리와 제품검사를 거쳐 출고됩니다.
- 2 사용자의 정상적인 사용상태에서 하자가 발생했을 경우 보증서의 내용 대로 1년 이내에 구입처나 A/S센터에서 제품교환 또는 무상서비스를 받으실 수 있습니다.
- 3 보증기간이더라도 비용을 받는 경우는 다음과 같습니다.
 - 사용자의 과오로 인한 하자 또는 파손인 경우
 - 부당한 수리 또는 개조로 인한 하자 또는 파손인 경우
 - 천재지변에 의한 하자 또는 파손인 경우
 - 구매 후 이동 또는 낙하등에 의한 하자 또는 파손인 경우
 - 사용설명서 내의 위험, 경고 또는 주의사항을 지키지 않아 발생한 하자인 경우
- 4 본 증서를 잘 보관하시고 서비스를 받으시고자 할 경우 보증서의 내용을 기록하여 제품과 함께 보내주십시오.

보증기간:	구입일로 부터 1년
제품명:	
모델명:	
구입일자:	
구입처(상호):	
고객성명:	성별 남 • 여
고객주소:	
전화번호:	

*본 사용설명서에 예시되어 있는 제품의 사양과 디자인은 예고 없이 변경될 수 있습니다.

수입 판매원 콘에어코리아트레이딩주식회사 소비자상담실 : 1899-0209 A/S센터: 자사의 A/S대행업체인 필일렉 www.filelec.co.kr의 홈페이지를 통해서 가까운 A/S센터(전국 38개점)를 확인하세요
